



09884866-061901

Configuration

General | Signs | Schedule Messages | Instant Messages

Route Specific Defaults

Start Route Arrival Countdown timer at sign: 30 minute(s) Prior to Arrival

Sign Specific Defaults

Switch to Actual Time no more than 5 minute(s) prior to scheduled arrival

Send 0 duplicate message(s) to the sign: 1 second(s) after the original is sent

Turn on sign: 30 minute(s) before first route arrival (0 = do not turn off)

Shut off sign: 30 minute(s) after last route departure (0 = do not turn off)

A Bus is considered Delayed when it is 10 minute(s) behind schedule

Time of Day

Refresh time at the sign every 5 minute(s)

OK Cancel

212 214 216 218 210 200 220 225 230 235 240 245 250

FIG. 2

09084366 "061901

Configuration

General | **Signs** | Schedule Messages | Instant Messages

OnStreet Sign	RNetAddress ID	Time Pl Crossing
41st Avenue Northbound	1	32nd St @ Eastern Ave
41st Avenue Southbound	12	Boyson Drug Town
49th Avenue Northbound	3	Cedar Valley Nature Trail
49th Avenue Southbound	6	Council @ Northbrook
5th Avenue Northbound	5	CVN Trail Crossing
5th Avenue Southbound	9	F Ave @ Collins
70th Avenue Northbound	8	ILG Terminal
70th Avenue Southbound	2	Kenword Elementary
Aberdeen Northbound	11	Kenword Elementary
Aberdeen Southbound	4	Nixon Elementary
Airport Station Northbound	7	Noelridge Pool
Airport Station Southbound	13	North Side Parsons
Alderbridge Northbound	14	Robins Tower
Alderbridge Southbound	10	Robins Tower
Brighthouse Northbound	16	Rockwell Center (Garage)
Brighthouse Southbound	20	Rockwell Corporate
Broadway Northbound	17	Summit School

OK Cancel

300

FIG. 3

0984866 061901

Sign Definition

Sign Descriptor: **Burrard Station Southbound** *410*

Time Point Crossing: **F Ave @ Collins** *420*

Sign will display information about:
☒ Estimated Arrivals *430*
☐ Scheduled Departures *435*

RNet Sign ID: **19** *440*

Set these Parameters for each Route (or do nothing to use the defaults)

Route Name: **100: Kenwood / Main Plant** *460*

☒ Display this route on sign *450*

Direction Filters:
Northbound
Outbound
PULLIN
PULLOUT
Southbound *470*
Westbound

Start Route Arrival Countdown timer at sign: **15** minute(s) Prior to Arrival

Sign is located: **0** minute(s) before time point (0=located at time point)

745 **OK** **Cancel**

← 400

FIG. 4

[illegible]

FIG. 5

500

09884866-061901

Scheduled Message

Sign: 41st Avenue South ☒ 610

Start Time: 11:00:00 AM 620

End Time: 1:00:00 PM 630

Message: ☐ Message 1 ☐ Message 2 ☐ Message 3 650

Message: Eat at Joe's Pizza.. 640

← 600

FIG. 6

09884866-061901

214 216 218

212

700

710

735

745

755

760

FIG. 7

780

782

784

786

788

790

792

794

796

798

800

802

804

806

808

810

812

814

816

818

820

822

824

826

828

830

832

834

836

838

840

842

844

846

848

850

852

854

856

858

860

862

864

866

868

870

872

874

876

878

880

882

884

886

888

890

892

894

896

898

900

902

904

906

908

910

912

914

916

918

920

922

924

926

928

930

932

934

936

938

940

942

944

946

948

950

952

954

956

958

960

962

964

966

968

970

972

974

976

978

980

982

984

986

988

990

992

994

996

998

1000

Configuration

General Signs Schedule Messages Instant Messages

Message Currently Displayed at Sign

Sign: Lansdowne NorthBc Refresh

Message One: Bus is Delayed Stop Msg

Message Two: One in Ice on Road Stop Msg

Message Three: Good afternoon Stop Msg

Priority Instant Message

Instant Messages are priority messages that will interrupt scheduled message service. Instant messages will be displayed until manually stopped.

Sign: Lansdowne NorthBc

Current Message: Good afternoon... Send Msg

Message One Message Two Message Three

OK Cancel